

Rubber Prep (Pre-Buff) Instructions



These instructions apply to all 31Inc Rubber Prep (Pre-Buff) Solutions.

For more information call 1.800.438.3302
For SDS Information Visit www.31inc.com

Directions

1. Locate area to be repaired in tire or on inner-tube.
2. Apply **RUBBER PREP (PRE-BUFF)** to area to be buffed.
3. Scrape clean with an inner-liner scraper, removing all fluid, contaminants, and mold lubricants from tire.
4. For tubes, use a manual buffer only to texturize repair area. For tires, use a mechanical buffer to buff repair area to a velvety RMA #1 texture. **DO NOT** reapply **RUBBER PREP (PRE-BUFF)** after buffing. (this will affect repair unit adhesion)
5. Proceed with repair following industry recommended tire repair procedures.

For more information,
call (800) 438-3302.

REV 03.07.2016